

Outside Plant Combi-Cord Be Equipped for Every Environment



*Buttset not included

New mini OSP Combi-Cord equips tech for testing in C.O., CEV and Building entrance 5 pin locations. Choice of plug-ins available upon request.

- Construct your own Combi-Cords.
- Choice of plug-ins available.
- Designed for all major Telco standardized buttsets.

1.5 Foot Combi Cord Extension
time saving testing ease
(L4 463A - L1 Alligator Clips - L3 526A - L2 453A)

Patented
Waterproof
Buttset Cord

Patented Snagless
L-Plug

RJ11 L-Plug

Patented RJ11 adapter plug allows tech to plug into wall jacks, SNI at the main point of residential "D" mark.

Complete Kit Part Number: **KT 290551** Buttset Cord Part Number: **TC 162202** Combi Extension Cord Part Number: **TC 162203**

WESTEK.COM

2450 17th Ave. Suite 200, Santa Cruz, CA 95062 Ph: 800-526-2673 Fax: 800-526-3299