

Coaxial Cross Connect and Patch Cords



TC-358A 358A to 358A



TC-440A 440A to 440A



TC-440T 440A to 440A with Tracers



TC-452 440D to 440D with Locking Tabs



TC-452T 440D to 440D with Locking Tabs and Tracers

PHONE: 1-800-526-2673

WESTEK
Electronics, Inc.

FAX: 1-800-526-3299

Coaxial Cross Connect and Patch Cords



TC-500 BNC to BNC



TC-500T BNC to BNC w/Tracer



TC-LCP LCP to LCP



TC-LCC LCC to LCC



TC-LCCT LCC to LCC w/Tracer

PHONE: 1-800-526-2673

WESTEK
Electronics, Inc.

FAX: 1-800-526-3299

Coaxial Cross Connect and Patch Cords



TC-458A 358A to 440A



TC-558 358A to BNC



TC-540 440A to BNC



TC-540T 440A to BNC with Tracers

PHONE: 1-800-526-2673

WESTEK
Electronics, Inc.

FAX: 1-800-526-3299

Coaxial Cross Connect and Patch Cords



TC-LCP440 440A to LCP



TC-440ALCC 440A to LCC



TC-552T 440D to BNC with Locking Tabs and Tracers




TC-531 LCC to BNC

PHONE: 1-800-526-2673

WESTEK
Electronics, Inc.

FAX: 1-800-526-3299

Coaxial Cross Connect and Patch Cords



TC-D358T Dual 358A to Dual 358A with Tracers



TC-450C Dual 440A to Dual 440A with Tracers



TC-D452T
Dual 440D to Dual 440D with Locking Tabs & Tracers



TC-DLCCT Dual LCC to Dual LCC with Tracers



TC-D500T Dual BNC to Dual BNC with Tracers

PHONE: 1-800-526-2673


WESTEK
Electronics, Inc.

FAX: 1-800-526-3299


Coaxial Cross Connect and Patch Cords




TC-D540 Dual 440A to Dual BNC



TC-D552T Dual 440D to Dual BNC w/Tracers



TC-D652T
Dual 440D to Dual DLCC with Locking Tabs & Tracers



TC-D531T Dual BNC to Dual LCC with Tracers

PHONE: 1-800-526-2673

WESTEK
Electronics, Inc.

FAX: 1-800-526-3299